# HIGHLIGHT SP-SUN Installation Manual





# Whyus?

# **Innovative Technology**

High-efficiency solar and advanced LEDs deliver superior performance, long life, and maximum ROI.

# **Photometric**

We conduct photometric measurements on all our products to ensure optimal performance and compliance with industry standards

# **Versatile Lightning**

We designs and install solar-powered lightning systems tailored for all kind of locations such as streets, parks, pathways, homes, etc.

# **Global Reach**

Worldwide success proves our adaptability and regulatory expertise.

# **Sustainable Savings**

These solutions enhance safety, promote sustainability and providing significant energy and cost saving.

SolarPath is dedicated to delivering architectural and commercial-grade solar lighting that can be customized to meet specific client requests, both in technical specifications and aesthetic design, ensuring a perfect fit for a diverse range of needs.


# Warranty







# Wire Diagram





## Materials in Package



- 1: All MC4 male connector (including master and sub modules) are positive 18/36V+. And all MC4 female connector (including master and sub modules) are negative 18/36V-.
- 2: The type of MC4 connectors at two sides of MASTER MODULE are exactly same. That is to say: you can use either of two sides to connect to the all in two solar light head or other device in the same way as using regular solar panel.
- 3: MC4 adapters must be used between two solar cylinders.

MC4 Female connector

4 : One mini male connector of master moduler is positive 18/36V+. The other side is negative 18/36V-. THEN accordingly: One mini female connector of sub moduler is Negative 18/36V-. And the other mini female connector on the other side is positive 18/36V+.

(The polarity mini connectors between sub module and master module are contrary.)

5 : ALL mini male and female connectors between sub module and master module should be connected to complete the whole system connection.

### **Required Tools**



Electric Allen Wrench forM8 set screws



Mini Male connector

Mini Femaleconnector

Allen Wrench for M8 set screws


## **VERY IMPORTANT:**

DO NOT CONNECT the MC4 male and female connector of the LAST MODULE.

Just leave them there or cut the connectors off.

OR

# **Connection Between Modules**









Use the screwdriver to fix the screws into the modular bracket at the proper position according to the diameter of the part of the pole where the modular brackets to be mounted.



Buckle the modular brackets on the pole, and Lock the two parts as one unit, make sure two parts are at same level (VERY IMPORTANT).



Connect the two parts of brackets and make the junction area flat and without any tilt. This step is very important. or the module will be tilted.



Fasten the 6 pieces of screws with driver, make sure the pole is in the exact middle of the brackets.



Make sure the brackets are mounted very tight and strong enough, it can hold 110lbs.



Put the first master module on the brackets in the right position.




With another person's help, Install the sub module from the top of master module, and slide down the sub module carefully, but hold it when sub module reaches the brackets with 20cm distance.



Connect the male and female mini connectors between sub module and master module.



After connection of the cables of last step, put down the sub module carefully, and put the two modules on the brackets at the best position.








Put second brackets over the module in opposite direction to the bottom brackets. Install it in the same way as installing the first brackets.



Make sure the two MC4 cables are outside through the third brackets. (Ready to install the next modules.)



Connect the MC4 connectors and put it back inside of the module tube. (It will be invisible from outside.)



Adjust the position of the brackets at the best position. Similarly, let the pole in the middle of the hexagon brackets.



Put the second master module on the bracket in the same way as 6 mentioned



Put the second sub module on the bracket in the same way as mentioned.

Fasten the 6 pieces screws with driver carefully.

Repeat the operations as 8 9 10 to complete the pending installation.






Finally connect the last two MC4 connectors on top of pole to solar light head directly.



Put the third brackets over the second brackets, and take out the two MC4 cables of first modules through the third brackets.

### NOTE:

Let the two brackets fit snugly through the three positioning holes.









# **Solar Module Dimensions**



Hexagon



Octagon




Decagon




Dodecagon




Vertical Solar Tube



OCTAGON 8 Sides A =10.62" B =11.41" C =7.48"









**DECAGON** 

10 Sides A = 14.17" B = 13.38" C = 10.23"





**DODECAGON** 

12 Sides A = 16.14" B = 16.73" C = 12.99"



D6.29"\*L40.94"





D9.44"\*L40.94"



# Contact us

+1.201.490.4499

Toll free: 1.888.333.SOLAR (7652)

contact@solarpathusa.com

www.solarpathusa.com