

HIGHLIGHT SP-SRL-360

Installation manual



Whyus?

Innovative Technology

High-efficiency solar and advanced LEDs deliver superior performance, long life, and maximum ROI.

Photometric

We conduct photometric measurements on all our products to ensure optimal performance and compliance with industry standards

Versatile Lightning

We designs and install solar-powered lightning systems tailored for all kind of locations such as streets, parks, pathways, homes, etc.

Global Reach

Worldwide success proves our adaptability and regulatory expertise.

Sustainable Savings

These solutions enhance safety, promote sustainability and providing significant energy and cost saving.

Warranty

SolarPath is dedicated to delivering architectural and commercial-grade solar lighting that can be customized to meet specific client requests, both in technical specifications and aesthetic design, ensuring a perfect fit for a diverse range of needs.

HIGHLIGHT SP-SRL-360


Installation manual

Post Top Installation Step


1.Remove the Screw on the light fixture




2.Put the light on the lamp pole



3.The screw alignment hole



4.Tightening the screw



Sleeve diameter- 3.14"



Sleeve diameter- 3.14"

Notice:

Turn on the light after installing the light fixture, and then adjust the color temperature to prevent the lamp from falling accidentally due to dazzling. You must turn off the CCT button before turning off the light.



Contact us



+1.201.490.4499

Toll free: 1.888.333.SOLAR (7652)



contact@solarpathusa.com



www.solarpathusa.com